

. ..

Power LED			
	11		

Description	
Start phase 1. device is not yet ready for operation	
Start phase 2. device is not yet ready for operatio	
Normal operation	

Uplink LED	Description	Possible cause of error
	Start phase 1. device is not yet ready for operation	
	Start phase 2. device is not yet ready for operation	
	Configuration mode is active	
	Normal operation	
	No connection to the local Network	 The network cable is not plugged in or there is no device (e.g. switch) at the other end of the network cable. Network cable defective
	Can't obtain an IP address	There is no DHCP server in the network segment of the HOOC Connect.
	Default gateway is unreachable	 There is no default gateway (router) in the network segment of the HOOC Connect. Default gateway blocks ICMP requests.
	DNS Server is unreachable	The DNS server used is not configured correctly. The DNS server (local or provider's) cannot be reached. If the provider's DNS server is used, the firewall may block access (e.g. 8.8.8.ª - google).
	No connection to HOOC Cloud	 There is no internet connection. Port 443 (outgoing) may be blocked by the firewall. You may be using a web proxy. The connection to the HOOC Cloud does not work behind a Webproxy.

Status LED				
III III				

Description	Possible cause of error
Start phase 1. device is not yet ready for operation	
Start phase 2. device is not yet ready for operation	
Normal operation	
Processor temperature greater than 80 °C	Operating ambient temperature too high
No connection to time server	 There is no internet connection. Port 443 (outgoing) may be blocked by the firewall. You may be using a web proxy. The connection to the HOOC Cloud does not work behind a Webproxy.
No connection to log server	 There is no internet connection. Port 10514 (outgoing) may be blocked by the firewall. This error can be ignored because the log server is not necessarily used.